


m o o o i

RAIMOND 199, 163, 127





1

NOTICE: Fragile; move lamp only in packaging.



2




Cable stopper



NOTICE: Raimond 199 = 12 KG
Raimond 163 = 7,5 KG
Raimond 127 = 4,5 KG

min: 0,8 m


NOTICE: Sharp edges,
handle with care.




m o o o i

RAIMOND 199, 163, 127


3




4



IMPORTANT NOTE
MAKE SURE THE EXCESS CABLE IS
SHORTER THAN 10CM (4")




BLACK = -
RED = +




m o o o i

RAIMOND 199, 163, 127

5



6




m o o o i


RAIMOND 199, 163, 127

REPLACE LED

Spare part bag:




1




2

NOTICE: Sharp edges,
handle with care.



POSITION OF LED




Replace broken led by repeating step
1 and 2 in reversed order.

m o o o i

RAIMOND 199, 163, 127

1

REMOVE SACK



2

FOLD UP FRAME

